



Handle and Valve Assembly Instructions

- Widespread Lavatory
- Widespread Kitchen
- Roman Tub Trim

Step One

Insert valve body (H) through hole in sink from underneath side. Note: cartridge (G) is pre-assembled into valve body.

Step Two

Place o-ring (F) into groove on underneath side of self-locating top locknut (E) with shoulder side down. Thread top locknut (E) onto valve body until it stops. Secure valve to sink by tightening bottom valve locknut under sink. The valve is now pre-set at correct height.

Step Three

Thread stem nut adapter (D) onto valve cartridge.

Step Four

Place trim ring (C) and bell (B) over valve assembly.

Step Five

Install handle (A) onto valve by threading stem nut on bottom of handle into stem nut adapter (D) securing the bell (B) and trim ring (C) firmly to top of sink.

